

## Drilling jig TECTUS TE 526/527 3D

For drilling of screw holes with block frames and blind frames



### Notes

#### Fitting instructions

1. Fasten drilling jig in the existing hinge routing.
2. Drill screw holes with TECTUS TE 526/527 3D drilling jig and  $\varnothing 3,0$  mm (0.118") drill bit.

#### Scope of supply

- 1 x drilling jig
- 1 x drill bit  $\varnothing 3,0$  mm (0.118")
- 1 x fitting instruction

### Suitable for

TE 526 3D	commercial wood frame
TE 527 3D	commercial wood frame

### Item versions

Finish	without (SW 000)
VPE	pack of 1
DIN	non-handed
ITEM NO.	5 250672 0 00001
ITEM NO. (SAP)	500005066
EAN	4015471093426

